

伊勢崎市文化会館大ホール DMXチャンネル表

DMX.CH	負荷回路名称		DMX.CH	負荷回路名称		DMX.CH	負荷回路名称		DMX.CH	負荷回路名称	
1	客席 1		31			61	2BL 1		91	PS 7	
2	客席 2		32			62	2BL 2		92	PS 8	
3	客席 3		33			63	2BL 3		93	PS 9	
4	客席 4		34			64	2BL 4		94	1SL 1	
5			35			65	2BL 5		95	1SL 2	
6			36			66	2BL 6		96	1SL 3	
7			37			67	2BL 7		97	1SL 4	
8			38			68	2BL 8		98	1SL 5	
9	客席 5		39			69	2BL 9		99	1SL 6	
10	客席 6		40			70	2BL 10		100	1SL 7	
11	客席 7		41			71	2BL 11		101	1SL 8	
12	客席 8		42			72	2BL 12		102	1SL 9	
13			43			73	3BL 1		103	1SL 10	
14			44			74	3BL 2		104	1SL 11	
15			45			75	3BL 3		105	1SL 12	
16			46			76	3BL 4		106	1SL 13	
17	客席 9		47			77	3BL 5		107	1SL 14	
18			48			78	3BL 6		108	1SL 15	
19			49	1BL 1		79	3BL 7		109	1SL 16	
20			50	1BL 2		80	3BL 8		110	2SL 1	
21			51	1BL 3		81	3BL 9		111	2SL 2	
22			52	1BL 4		82	3BL 10		112	2SL 3	
23			53	1BL 5		83	3BL 11		113	2SL 4	
24			54	1BL 6		84	3BL 12		114	2SL 5	
25			55	1BL 7		85	PS 1		115	2SL 6	
26			56	1BL 8		86	PS 2		116	2SL 7	
27			57	1BL 9		87	PS 3		117	2SL 8	
28			58	1BL 10		88	PS 4		118	2SL 9	
29			59	1BL 11		89	PS 5		119	2SL 10	
30			60	1BL 12		90	PS 6		120	2SL 11	

伊勢崎市文化会館大ホール DMXチャンネル表

DMX.CH	負荷回路名称	DMX.CH	負荷回路名称	DMX.CH	負荷回路名称	DMX.CH	負荷回路名称
121	2SL 12	151	4SL 8	181	花F 上 2	211	上下共通 7
122	2SL 13	152	4SL 9	182	花F 下 1	212	上下共通 8
123	2SL 14	153	4SL 10	183	花F 下 2	213	FC 上 10
124	2SL 15	154	4SL 11	184	オケピ 1	214	FC 下 1
125	2SL 16	155	4SL 12	185	FC 上 5	215	FC 下 2
126	3SL 1	156	4SL 13	186	FC 上 6	216	FC 下 3
127	3SL 2	157	4SL 14	187	FC 上 7	217	FC 下 4
128	3SL 3	158	4SL 15	188	FC 上 8	218	FC 下 9
129	3SL 4	159	4SL 16	189	FC 下 5	219	FC 下 10
130	3SL 5	160	1FR 上 1	190	FC 下 6	220	FC 奥 5
131	3SL 6	161	1FR 上 2	191	FC 下 7	221	FC 奥 6
132	3SL 7	162	1FR 上 3	192	FC 下 8	222	FC 奥 7
133	3SL 8	163	1FR 上 4	193	オケピ 2	223	FC 奥 8
134	3SL 9	164	1FR 上 5	194	上前共通 9	224	FC 奥 1
135	3SL 10	165	1FR 下 1	195	上前共通 10	225	FC 奥 2
136	3SL 11	166	1FR 下 2	196	上前共通 11	226	FC 奥 3
137	3SL 12	167	1FR 下 3	197	下前共通 12	227	FC 奥 4
138	3SL 13	168	1FR 下 4	198	下前共通 13	228	LH 1
139	3SL 14	169	1FR 下 5	199	下前共通 14	229	LH 2
140	3SL 15	170	2FR 上 1	200	FC 上 1	230	LH 3
141	3SL 16	171	2FR 上 2	201	FC 上 2	231	LH 4
142	3SL 17	172	2FR 上 3	202	FC 上 3	232	LH 5
143	3SL 18	173	2FR 下 1	203	FC 上 4	233	LH 6
144	4SL 1	174	2FR 下 2	204	上下共通 1	234	LH 7
145	4SL 2	175	2FR 下 3	205	上下共通 2	235	LH 8
146	4SL 3	176	F 1	206	上下共通 3	236	FC 奥 9
147	4SL 4	177	F 2	207	上下共通 4	237	FC 奥 10
148	4SL 5	178	F 3	208	FC 上 9	238	FC 奥 11
149	4SL 6	179	F 4	209	上下共通 5	239	FC 奥 12
150	4SL 7	180	花F 上 1	210	上下共通 6	240	トヤ 上 1

伊勢崎市文化会館大ホール DMXチャンネル表

DMX.CH	負荷回路名称		DMX.CH	負荷回路名称		DMX.CH	負荷回路名称		DMX.CH	負荷回路名称	
241	トヤ下1		271	UH 16		301			331		
242	TL上1		272	UH 17		302			332		
243	TL上2		273	UH 18		303			333		
244	TL下1		274	1CL 1		304			334		
245	TL下2		275	1CL 2		305	1CL 5		335		
246	前WC上1		276	1CL 3		306	1CL 6		336		
247	前WC上2		277	1CL 4		307	1CL 7		337		
248	前WC上3		278	2CL 1		308	1CL 8		338		
249	前WC上4		279	2CL 2		309	1CL 9		339		
250	前WC上5		280	2CL 3		310	1CL 10		340		
251	前WC上6		281	2CL 4		311	1CL 11		341		
252	スノコ1		282			312	1CL 12		342		
253	スノコ2		283			313	2CL 5		343		
254	前WC下1		284			314	2CL 6		344		
255	前WC下2		285			315	2CL 7		345		
256	前WC下3		286			316	2CL 8		346		
257	前WC下4		287			317	2CL 9		347		
258	前WC下5		288			318	2CL 10		348		
259	前WC下6		289	UH 7		319	2CL 11		349		
260	トヤ下2		290	UH 8		320	2CL 12		350		
261	トヤ上2		291	UH 9		321			351		
262	UH 1		292	UH 10		322			352		
263	UH 2		293			323			353		
264	UH 3		294			324			354		
265	UH 4		295			325			355		
266	UH 5		296			326			356		
267	UH 6		297	UH 11		327			357		
268	UH 13		298	UH 12		328			358		
269	UH 14		299			329			359		
270	UH 15		300			330			360		

伊勢崎市文化会館大ホール DMXチャンネル表

DMX.CH	負荷回路名称		DMX.CH	負荷回路名称		DMX.CH	負荷回路名称		DMX.CH	負荷回路名称	
361			391			421			451		
362			392			422			452		
363			393			423			453		
364			394			424			454		
365			395			425			455		
366			396			426			456		
367			397			427			457		
368			398			428			458		
369			399			429			459		
370			400			430			460		
371			401			431			461		
372			402			432			462		
373			403			433			463		
374			404			434			464		
375			405			435			465		
376			406			436			466		
377			407			437			467		
378			408			438			468		
379			409			439			469		
380			410			440			470		
381			411			441			471		
382			412			442			472		
383			413			443			473		
384			414			444			474		
385			415			445			475		
386			416			446			476		
387			417			447			477		
388			418			448			478		
389			419			449			479		
390			420			450			480		

伊勢崎市文化会館大ホール DMXチャンネル表

DMX.CH	負荷回路名称		DMX.CH	負荷回路名称		DMX.CH	負荷回路名称		DMX.CH	負荷回路名称	
481			511								
482			512								
483											
484											
485											
486											
487											
488											
489											
490											
491											
492											
493											
494											
495											
496											
497											
498											
499											
500											
501											
502											
503											
504											
505											
506											
507											
508											
509											
510											